



12 01 2011




PUSH-PULL FLAP DRAWER ASSEMBLY (OPTIONAL)




4WG DRAWER ASSEMBLY (OPTIONAL)

	DRAWER ASSEMBLY PARTS
POSITION NUMBER	PART NAME
1	WARMER DRAWER BODY
4	SCREW (3.9*9.5)
5	DRAWER INNER COVER
6	DRAWER PANEL
14	BOTTOM INSULATION COVER
35	WARMER DRAWER BODY GUIDE (RIGHT/LEFT)
37	DRAWER PANEL STOPPER
67	DRAWER BRACKET CONTACT SCREW
127	FLAP HINGE COUNTERPART SPRING
128	FLAP DRAWER HANDLE
132	FLAP DRAWER LOCKING LATCH
165	FLAP DRAWER HANDLE CONTACT SCREW
199	FLAP DRAWER BUMPER
227	FIXED DRAWER PANEL ASSEMBLY BRACKET
368	FLAP DRAWER LOCKING CONTACT SCREW
369	FLAP DRAWER LOCKING COUNTERPART CONTACT SCREW
371	FLAP DRAWER HINGE (RIGHT/LEFT)
372	FLAP DRAWER LOCKING BRAKET
373	FLAP DRAWER LOCKING(MINI LATCH)
384	FLAP DRAWER LOCKING COUNTERPART(MINI LATCH)
389	DRAWER BOX
607	4WG DRAWER RAIL GROUP (60*60,50*60)

The exploded views given in this document are generic. They include all possible versions of the product. For specific part codes, please refer to the bom list of regarding model





*Metal frames on outer glass, handle types, handle taps and brackets are optional. Your cooker may be different cosmetically.

(OPTIONAL)

(POSITION NO 49)


WITH INOX ADD-ON TYPES

(OPTIONAL)


(OPTIONAL)

(POSITION NO 377)


OVEN DOOR OUTER GLASS ASSEMBLY PARTS		
POSITION		
NUMBER	PART NAME	
4	SCREW (KNURLED, 3.9*9.5, BLACK)	
49	HANDLE ASSEMBLY GROUP	
50	INNER GLASS ASSEMBLY	
51	INNER LID TOP CONTACT SCREW	
52	OVEN DOOR HINGE	
53	OVEN DOOR HANDLE ASSEMBLY STUD	
54	OUTER GLASS ASSEMBLY	
55	HANDLE BRACKET / BRACKET WITH CAP (LEFT / RIGHT)	
56	HANDLE BODY	
67	REMOVABLE INNER GLASS SPRING CONTACT SCREW	
107	WASHER	
130	SIDE CLOSING PROFILE (FOR FLAT OVEN DOOR WITH FULL GLASS)	
173	DOUBLE GLAZED OVEN DOOR METAL TRIM CONTACT SCREW	
204	HANDLE TAP	
211	HANDLE ASSEMBLY GASKET	
220	INTERVAL FRONT PANEL SPRING	
237	DOUBLE GLAZED OVEN DOOR METAL TRIM	
238	OVEN DOOR HANDLE CONTACT SCREW	
239	HANDLE FIXING BUSH	
240	SILICONE WASHER	
262	REMOVABLE INNER GLASS SPRING (LEFT / RIGHT)	
302	HANDLE BRACKET CONTACT SCREW	
374	SOLID TYPE OVEN DOOR ASSEMBLY (3D)	
375	SOLID TYPE OVEN DOOR (FLAT / OBLIQUE)	
376	SOLID TYPE OVEN DOOR ASSEMBLY	
377	OVEN DOOR GROUP	
"The exploded views given in this document are generic. They include all possible versions		
of the product. For specific part codes, please refer to the bom list of regarding model."		




WIRE SHELF CAVITY ASSEMBLY WITH / WITHOUT CATALYTIC PANEL OPTIONAL: DOUBLE TELESCOPIC RAILS (R / L)



WIRE SHELF CAVITY ASSEMBLY WITH / WITHOUT CATALYTIC PANEL OPTIONAL : TELESCOPIC RAIL (R / L)




WIRE SHELF CAVITY ASSEMBLY WITH / WITHOUT CATALYTIC PANEL (OPTIONAL)



CAVITY ASSEMBLY WITH CATALITIC SHELF (OPTIONAL)


RIGHT

LEFT



CAVITY ASSEMBLY PARTS		
POSITION		
NUMBER	PART NAME	
2	OVEN LIGHT	
4	SCREW (3.9*9.5)	
7	REAR INSULATION COVER	
9	FAN MOTOR	
10	CAVITY	
12	HINGE COUNTERPART (LEFT / RIGHT)	
13	HINGE COUNTERPART FRONT CONTACT SCREW	
14	BOTTOM INSULATION COVER	
15	TRAY (DEEP / SHALLOW , BLACK)	
16	OVEN DOOR GASKET	
17	GRID (LOCKED, W. TELESCOPIC RAIL)	
18	THERMOSTAT BULB BRACKET	
19	FAN COVER	
20	RING TUBULAR HEATING ELEMENT	
21	FAN IMPELLER	
61	TELESCOPIC RAIL (RIGHT, LEFT)	
71	HINGE COUNTERPART SIDE CONTACT SCREW	
80	SCREW (KNURLED, M 4*6)	
106	DEEP TRAY GRID	
110	BOTTOM HEATING ELEMENT	
111	BOTTOM HEATING ELEMENT HOLDER	
112	TOP AND GRILL HEATING ELEMENT	
114	TOP HEATING ELEMENT BULB BRACKET	
115	TURNSPIT GRILL	
116	TURNSPIT SKEWER	
117	TURNSPIT MOTOR	
119	TURNSPIT HOLE COVER	
143	TURNSPIT HOUSE (or alternative: TURNSPIT GRILL)	
	CATALYTIC PANEL WITH WIRE SHELF (ENAMELLED)	
144	SHELF COVER (RIGHT/LEFT, CATALYTIC ENAMELLED)	
174	TRAY GRID	
253	WIRE SHELF (RIGHT / LEFT)	
255	WIRE SHELF FIXING SCREW	
263	GRILL PAN	
264	GRILL PAN HANDLE	
265	TRAY SET (SMALL, BLACK)	
266	TELESCOPIC RAIL CONTACT SCREW	
454	LIMIT THERMOSTAT NC 125°C (OPTIONAL)	
456	SHISH KEBAB ACCESSORY	
479	THERMOSTAT BULB HOLDER (ELECTRIC)	
515	ELECTRONIC THERMOSTAT	
530	EYE SCREW (M5*12,AISI304)	
	ed views given in this document are generic. They include all	
nossible versions of the product		


possible versions of the product.



CONTROL PANEL ASSEMBLY PARTS	
POSITION	
NUMBER	PART NAME
4	SCREW (3.9*9.5)
70	INNER PANEL
72	FRONT PANEL GROP (GLASS / METAL)
73	KNOB RING
74	KNOB SPRING
77	SIGNAL LAMP LENS
78	CHILD LOCK
79	SIGNAL LAMP BODY
80	ELECTRICAL KOMPONENT CONTACT SCREW
81	FUNCTION SELECTOR SWITCH / HOTPLATE SWITCH
82	CAPILLARY THERMOSTAT
90	KNOB - ELECTRICAL
113	TIMER (MECHANIC / DIGITAL / ANALOG)
122	TIMER LENS
124	TIMER HOLDER (DIGITAL / ANALOG)
137	TIMER BUTTON
188	ENERGY REGULATOR
324	FRONT PANEL INSULATION (IZOPAN)


"The exploded views given in this document are generic. They include all possible versions of the product.


For specific part codes, please refer to the bom list of regarding model."



COOKTOP ASSEMBLY PARTS		
POSITION		
NUMBER	PART NAME	
4	SCREW (3.9*9.5)	
8	HOT SURFACE INDICATOR LIGHT	
22	HOT SURFACE INDICATOR LIGHT HOLDER	
40	HIGHLIGHT HEATING FIXING BRACKET ASSEMBLY CONTACT SCREW	
182	VITROCERAMIC HOB BOTTOM COVER	
184	HIGHLIGHT HEATING (Ø145, Ø180, Ø210)	
190	HIGHLIGHT HEATING FIXING BRACKET ASSEMBLY	
249	CERAMIC GLASS ASSEMBLY	
"The explod	ed views given in this document are generic. They include all possible	

"The exploded views given in this document are generic. They include all possible versions of the product. For specific part codes, please refer to the bom list of regarding






SIDE PANEL ASSEMBLY PARTS	
POSITION	
NUMBER	PART NAME
4	SCREW (3.9*9.5)
27	COOKTOP ANGLE IRON (LEFT / RIGHT)
28	REAR TOP PANEL
29	REAR PANEL
30	TERMINAL BOX
32	SIDE PANEL
33	REAR PLINTH
34	ADJUSTABLE WHEEL
36	FRONT PLINTH
38	EXHAUST (56/66)
148	CONCRETE WEIGHT
194	REAR BOTTOM LID
229	EXTRA BOTTOM SUPPORT
290	BATTERY BOX
291	BATTERY

"The exploded views given in this document are generic. They include all possible versions of the product.

For specific part codes, please refer to the bom list of regarding

OVEN DOOR HANDLES (OPTIONAL) HANDLES WITHOUT TAP & BRACKET



KNOBS (ONLY FOR FS - OPTIONAL)

