


90 CM FREE STANDING CAVITY ASSEMBLY


COOKER





90 CM FREE STANDING COOKER CAVITY ASSEMBLY













CAVITY ASSEMBLY GROUP POSITION NUMBER: 10


90 CM FREE STANDING VITROCERAMIC COOKER CONTROL PANEL




The exploded views given in this document are generic. They include all possible versions of the product. For specific part codes ,please refer to the bom list of regarding model.





90 CM FREE STANDING VITROCERAMIC COOKER CONTROL PANEL



90 CM FREE STANDING VITROCERAMIC COOKER COOKTOP ASSEMBLY









[&]quot;The exploded views given in this document are generic. They include all possible of versions product. For specific part codes ,please refer to the bom list of regarding model."


90 CM FREE STANDING VITROCERAMIC COOKER COOKTOP ASSEMBLY







"The exploded views given in this document are generic. They include all possible of versions product. For specific part codes ,please refer to the born list of regarding model."

90 CM FREE STANDING VITROCERAMIC COOKER COOKTOP ASSEMBLY










[&]quot;The exploded views given in this document are generic. They include all possible of versions product. For specific part codes ,please refer to the born list of regarding model."

90 CM FREE STANDING LID ASSEMBLY


COOKER









90 CM FREE STANDING COOKER OVEN DOOR ASSEMBLY










90 CM FREE STANDING COOKER OVEN DOOR ASSEMBLY







90 CM FREE STANDING COOKER DRAWER ASSEMBLY






90 CM FREE STANDING COOKER SIDE PANEL ASSEMBLY





90 CM FREE STANDING (PROFESSIONAL/ STANDART) COOKER OVEN HANDLES (OPTIONAL)



90 CM FREE STANDING VITROCERAMIC COOKER SPARE PART LIST **POSITION** PART NAME NUMBER 2 / 618 **OVEN LIGHT / LAMP** 4 SCREW (3.9*9.5) 5 DRAWER INNER COVER DRAWER PANEL 6 HOT SURFACE WARNING LAMP GR. SINGLE 8 **FAN MOTOR** 9 10 **CAVITY** 12 HINGE COUNTERPART (LEFT /RIGHT) 13 **SCREW (M4*8)** 14 **BOTTOM INSULATION COVER (96)** 15 TRAY (DEEP / SHALLOW /GLASS) **OVEN DOOR GASKET** 16 17 GRID (LOCKED, W.TELESCOPIC RAIL) 19 **FAN COVER** 20 RING TUBULAR HEATING ELEMENT 21 **FAN IMPELLER** 22 HOT SURFACE INDIC. LIGHT HOLDER 28 **REAR TOP PANEL** 29 **REAR PANEL** 30 TERMINAL BOX 31 POWER CORD (PLUGGED / UNPLUGGED) 32 SIDE PANEL 34 ADJUSTABLE WHEEL 37 DRAWER PANEL STOPPER 38 **EXHAUST** 40 **SCREW (KNURLED, 3.5*9.5)** 50 **INNER GLASS ASSEMBLY** SCREW (COUNTERSUNK-HEAD, M5*10, BLACK) 51 52 OVEN DOOR HINGE OVEN DOOR HANDLE ASSEMBLY STUD 53 54 **OUTER GLASS ASSEMBLY** 55 HANDLE BRACKET 56 HANDLE BODY 60 **IGNITOR** 61 TELESCOPIC RAIL (RIGHT / LEFT) **SCREW (3.9*9.5, SLIM HEAD)** 67 70 **INNER PANEL** 71 SCREW (KNURLED, 3.9*6.5) **FRONT PANEL 72** 73 KNOB RING 74 **KNOB SPRING 75** DRAWER SILICONE STOPPER **77** SIGNAL LAMP LENS 79 SIGNAL LAMP BODY 80 **SCREW (M4*6)** 81 FUNC.SELECT.SWITCH 82 **CAPILLARY THERMOSTAT 240°C**

90 CM FREE STANDING VITROCERAMIC COOKER SPARE PART LIST

POSITION NUMBER	PART NAME
86	SCREW (COUNTERSUNK-HEAD, M3*8, LENTIL HEAD)
87	GLASS LID ASSEMBLY
88	GLASS LID HINGE LEFT/RIGHT
89	SCREW (KNURLED, M4*10)
90	KNOB (ELECTRIC)
91	NUT
103	THERMOCOUPLE FIXING NUT
104	GLASS LID BUMPER
106	DEEP TRAY GRID
107	WASHER
110	BOTTOM HEATING ELEMENT
111	BOTTOM HEATING ELEMENT HOLDER
112	TOP AND GRILL HEATING ELEMENT
113	TIMER (MECHANIC/DIGITAL/ANALOG)
114	TOP HEATING ELEMENT BULB BRACKET
115	TRUNSPIT GRID
116	TRUNSPIT SKEWER
117	TRUNSPIT MOTOR
122	TIMER LENS
130	SIDE CLOSING PROFILE
137	TIMER BUTTON
144	CATALYTIC PANEL WITH WIRE SHELF (ENAMELLED)
	SHELF COVER (RIGHT / LEFT ,CATALYTIC ENAMELLED)
149	SCREW (CIRCULAR-HEAD, 4.8*32)
170	SCREW (COUNTERSUNK-HEAD, 4.2*9.5)
173	SCREW (3.9*13)
175	SCREW (CIRCULAR-HEAD, M4*8, STAINLESS)
182	VITROCERAMIC HOB BOTTOM COVER
184	CERAN HEATER
188	ENERGY REGULATOR
190	HIGHLIGHT HEATING FIXING BRACKET ASSEMBLY
201	COOLING MOTOR
203	COOLING FAN DUCT
204	HANDLE TAP
206	GLASS LID FRO.PROFILE SILICON BUMPER
211	HANDLE ASSEMBLY BRACKET
212	EXHAUST PROTECTION COVER
213	EXHAUST LID
218	HINGE SIDE ASM SCREW
220	INTERVALFRONT PANEL SPRING
227	FIXED DRAWER PANEL ASSEMBLY BRACKET
237	DOUBLE GLAZED OVEN DOOR METAL TRIM
238	OVEN DOOR HANDLE SCREW
239	HANDLE FIXING BUSH
240	SILICONE WASHER

90 CM FREE STANDING VITROCERAMIC COOKER SPARE PART LIST

POSITION NUMBER	PART NAME
248	SCREW (KNURLED, 3.9*6.5,BLUNT TYPE)
249	CERAMIC GLASS ASSEMBLY
252	WIRE SHELF FIXING CLIP
253	WIRE SHELF (RIGHT / LEFT)
257	WOK BURNER SUPPORT
262	REMOVABLE INNER GLASS SPRING (LEFT/RIGHT)
266	SCREW (M4*4T,STAINLESS)
293	DOOR LOCK PIN
295	EXHAUST COVER
300	KNIFE BARRIER SUBPANEL
302	HANDLE BRACKET SCREW
310	FEMALE-FEMALE ADAPTOR
314	SCREW (CIRCULAR-HEAD, M4*12, SPIRAL,WHITE)
315	SCREW (COUNTERSUNK-HEAD,M4*15,BLACK)
328	WASHER (ENAMELLED,BLACK)
329	GRADUAL WASHER
330	SCREW (KNURLED, M4*4)
331	KNURLED WASHER Ø4
333	GLASS LID BACK PROFILE CAP
371	FLAP DRAWER HINGE RIGHT/ LEFT
376	FLAT TYPE OVEN DOOR GROUP WITH SMALL INNER GLASS
377	PROFILE TYPE OVEN DOOR GROUP
385	ENAMELLED COOKTOP FIXING CLIP
410	ANTI-TIP BRACKET HOLDER
413	GLASSLID COVERINGPLSPART
432	OVEN DOOR MIDDLE GLASS
450	GLASS LID HINGE COUNTERPART
452	LIMIT THERMOSTAT NO 200°C
479	THERMOSTAT BULB HOLDER
487	SCREW (KNURLED, M4*12, INOX)
521	WIRE SADDLE
540	TRUNSPIT HANDLE
559	FIXED DRAWER PANEL ASSEMBLY BRACKET
560	ANTI-TIP BRACKET
562	OIL INSULATION COVER
563	OIL INSULATION OUTER COVER
564	TURNSPIT HOLDER WIRE
565	HOSE HOLDER WIRE
566	TUBE HOLDER WIRE
567	BOTTOM PANEL SUPPORT SHEET GROUP
568	ADJUSTABLE FEET SIDE CLOSING SHEET
569	CAVITY FRONT FRAME (96,BLACK)
577	96 TUBE COMP HOSE TRANSITION GASKET
608	LIMITER BRACKET WITH SCREWING
653	APLUS CARD HOLDER PLASTIC
654	DOUBLE SPEED FAN MOTOR
The exploded	views given in this document are generic. They are include all possible versions of the product. For